

PALACE INTERNATIONAL LTD.
 HATCHWOOD PLACE
 FARNHAM ROAD
 ODIHAM
 HAMPSHIRE
 RG29 1AB
 UK

Email distribution:

Attention: **Dave Taylor**

Operator Code: **JC1**

(This code can be used for general communication with Jet-Care as well as on trend forms and iECHO GPA™ for identification.)

Contact: **Dave Taylor**

Telephone: **01256 701777**


Fax: **01256 701377**

Email: davetaylor@jet-care.com

iECHO GPA™ iECHO GPA is the free Jet-Care app for manually recorded engine trending. See video at <https://www.jet-care.com/gpa-iecho.html>



Current users are encouraged to maintain currency by:

- (1) Updating to the latest version.
- (2) Syncing the app to ensure the Operator and aircraft details are current.
- (3) Review and update the app default data settings to match their aircraft profile (Air Temperature, Air Speed and Fuel Flow type). See the app guide. 

Registration AC. Serial	AC. Make/Model Engine Type	#	Engine	Data Source	Trend Stage	Trends	First	Last	Age of Data (days)	Trend Status	See Comments Page
1 N40XR L40.2028	Bombardier Learjet 40 HONEYWELL TFE731-20BR-1B	1	116602	Electronic	Takeoff	1546	03-May-2005	09-Dec-2023	9	EARLY WARNING	Yes
		1	116602	Electronic	Cruise	740	30-Apr-2005	09-Dec-2023	9	EARLY WARNING	Yes
		1	116602	Manual	Cruise	1275	25-Jun-2005	08-Dec-2023	10	EARLY WARNING	Yes
		2	116603	Electronic	Takeoff	1462	30-Apr-2005	09-Dec-2023	9	Normal	
		2	116603	Electronic	Cruise	665	15-Jun-2005	09-Dec-2023	9	Normal	
		2	116603	Manual	Cruise	1276	25-Jun-2005	08-Dec-2023	10	Normal	




Registration: N40XR / Engine # 1: 116602

- ADVISORY - EARLY WARNING - Information received (email dated 9th December 2023) - Fri 8th Dec, amber CAS L ENGCMPTR FAULT QRH carried out, then white CAS CHECK L EDS

For your information aside from the code 239 (download DEEC's) the following faults were recorded in the downloads dated 9th December 2023;

Type	Date	Time	Code / Description /	
	Level	DId Ref	Engine	
Fault Code	2023-12-09	4325:07:35.9	5 N1 Signal Not Reasonable (N1 < 2% when N2 > 45%)	4
	22-AB250.222	116602		
Fault Code	2023-12-09	4325:07:40.1	1 N1 Monopole Circuit open	
	4 22-AB250.222	116602		
Fault Code	2023-12-09	4325:07:40.1	239 NOTICE DEEC power cycled after start (2%<N2<40%)	1
	22-AB250.222	116602		

Maintenance to carry out investigation / replacement of the N1 monopole (email dated 9th Dec).





